



## Capri 22 Sail Trim Guide

Wind Strength in Knots:	0-6	6-10	11-15	15-20	20+
Shroud Tensions (Full Turns)					
Uppers:	25	28	30	32	32
Lowers:	3	5	8	8	8
Mainsail Cunningham	None	None	Take out wrinkles	Take out wrinkles	On hard
Outhaul (inches from band)	2.5"	1.5"	Tight – At Band	Tight – At Band	Tight – At Band
Top Batten Angle	Parallel to Boom	Parallel to Boom	Open 5 Degrees	Open 10 Degrees	Open 10 Degrees
Upwind Vang Tension	None	None	Snug	Bend boom ¾"	Bend boom ¾"
Downwind Vang Tension	None	Snug	Snug	Main twist 5 degrees	Main twist 5 degrees
Upwind Boom Position	Centerline	Centerline	Centerline to 6" down	All the way down	Vang Sheet
Downwind Boom Position	45 degrees	Touching shroud	Touching shroud	Touching shroud	Touching shroud
Traveler (distance below centerline)	+8"	+4"	Center	-1'	-3
Genoa Foot from Shroud	Touching lifelines	Touching shrouds	Touching shrouds		
Genoa Leech from Spreader	6"	6"	1'		
Jib Leech in from Spreader Tip			2" Outside spreader tip	4" outside spreader tip	
Jib Trim: Jib Block to Jib Clew			15"	16"	
Jib Lead Position			Center of track	Center of Track	Back 2 holes from center
Jib Luff Tension			Smooth	Smooth	Smooth
Headsail Choice	Genoa	Genoa	Jib	Jib	Jib
Spinnaker Jibe Type	End for End	End for End	End for End	End for End	End for End